COCHRANE

ASSEMBLY INSTRUCTIONS EITEM#: 17808

Read instruction carefully prior to assembly .

Thank you for purchasing this quality product. Check carefully for small parts which may have come loose during shipment.

Remove all components from pack and place table top upside down on soft surface such as carpet or cloth to prevent scratching the finish . Identify and count all parts as specified below.

Q' TY

1 PC

1 PC

1L, 1R

1 PC 1L, 1R

Do not tighten bolts until assembly is complete

OUTLOOK

"PART LISTS"	
--------------	--

DESC

CHAIR BACK

WOOD SEAT

FRONT LEG

FRONT STRETCHER

SIDE STRETCHER

STT

1

2

4

5

"HARDWARE LISTS"

	STT	DESC	SIZE	Q' TY		
	А	()	BOLT (1/4" x 3")	4 PCS		
	в	()()	BOLT (Ø 1/4" x 2.36")	4 PCS		
	С	())))))))))))))))))))))))))))))))))))	BOLT (Ø 1/4" x 1.57")	2 PCS		
	D	O	LOCK WASHER (Ø 1/4")	10 PCS		
	Е	0	FLAT WASHER (Ø 1/4")	10 PCS		
_	F	Juiiii	SCREW (1 1/2")	6 PCS		
	G		ALLEN KEY (1/8")	1 PC		
		U	· · ·			

